

Your Converse 2300 is now ready for use.


Slot the holes on the back of the base over the screw heads and gently pull the phone down to fix it securely in place.

Insert the wall plugs if necessary, then insert the screws leaving about 5mm protruding from the wall on which to hang the phone.


Drill two holes in the wall 75-80mm vertically apart using an 8mm drill bit.

Unclip the stand from the base of the phone and remove it. Re-route the telephone line cord towards the bottom of the phone.

Important: Before wall mounting, check you are not drilling into any hidden wiring or plumbing. Make sure the telephone line cord will reach the wall socket.



Wall mounting (optional)



Fit the desk mounting plinth if required by positioning the plinth over the lugs and pushing it down into place, as shown by the blue arrows.

Attach the desk mounting plinth

General information

For information on safety instructions, cleaning, technical information or connecting to a switchboard, please refer to the 'General information' section in the full user guide at www.bt.com/producthelp

Guarantee

Your BT Converse 2300 is guaranteed for a period of 12 months from the date of purchase.

Subject to the terms listed below, the guarantee will provide for the repair of, or at BT's or its agent's discretion the option to replace the BT Converse 2300, or any component thereof, which is identified as faulty or below standard, or as a result of inferior workmanship or materials. Products over 28 days old from the date of purchase may be replaced with a refurbished or repaired product.

The conditions of this guarantee are:

- The guarantee shall only apply to defects that occur within the 12 month guarantee period.
- Proof of purchase is required.
- The equipment is returned to BT or its agent as instructed.

This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents.

This guarantee does not affect your statutory rights.

For further information within and outside the 12 month guarantee, please refer to the full user guide at www.bt.com/producthelp

Product disposal instructions

The symbol shown here and on the product means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life.

The Waste of Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increasing landfill.

Product disposal instructions for residential users

When you have no further use for it, please remove any batteries and dispose of them and the product as per your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.

Product disposal instructions for business users

Business users should contact their suppliers and check the terms and conditions of the purchase contract and ensure that this product is not mixed with other commercial waste for disposal.

R&TTE Directive & Declaration of Conformity

This product is intended for use within the UK for connection to the public telephone network and compatible switchboards.


This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive (1999/5/EC).

The Declaration of Conformity is published on the website www.bt.com/producthelp

If connecting to a switchboard you may need to adjust the dialling mode setting to P or T using the switch on the underside of the base. If in doubt, please consult your service provider.

3. Check that the Dialling Mode switch on the underside of the base is set to TB for tone dialling with timed break recall.

2. Plug the telephone line cord into the wall socket.



1. Plug mains power adaptor (item code 046397 white and 046406 black) into the socket marked P and plug the other end into the wall socket and switch the power on.

1 Set up

BT & British Gas
Working together, supporting energy saving products
BT & British Gas have joined forces to help our customers find new ways to save energy around the home, so we can all do our bit for the environment & save money too!

BT is a sustainability leader

To find out how we're making our products greener visit

bt.com/betterworld/products

Offices worldwide

The services described in this publication are subject to availability and may be modified from time to time. Services and equipment are supplied subject to British Telecommunications plc's respective standard conditions of contract. Nothing in this publication forms any part of a contract.

© British Telecommunications plc 2009.
Registered Office: 81 Newgate Street, London EC1A 7AJ.
Registered in England No. 1800000.

Designed and produced by The Art & Design Partnership Ltd.

Printed in China / Issue 3 / ADP12-09



BT Converse 2300 User Guide




1 Set up
2 Go!



Setting up is easy. Just follow the simple steps in this guide.


If you need further assistance, please visit our website www.bt.com/producthelp to view our advanced user guide.

Check box contents



Important: Only use the handset and line cord supplied in this box, or this product may not work.

Your phone



Using the menu
A range of functions and settings can be accessed through the main menu.

Press **Menu** to enter the menu.
Press **↑** or **↓** to scroll through the menu list.
When you reach the end of the list, the first option is displayed again.
To select an option, press **✓**.
To return to the previous menu display, press **×**.

1 The light will only flash when connected to a PBX switch or similar.
The light will not flash when used with network services, e.g. BT 1571.

2 Go!

Handset & Hearing Aid
Hearing aid wearers may benefit from switching their hearing aid to the middle T position and holding the earpiece up to the aid, not their ear. Please visit <http://www.btplc.com/inclusion/> for further practical advice on using hearings aids.

Making calls

Lift the handset and dial the phone number. Replace the handset to end the call.

Make a call using a headset

Headsets are not supplied. However, you can purchase headsets (with RJ11 jack) by visiting www.shop.bt.com

Plug the headset into the socket marked **Q** on the underside of the base.
Press **Headset** and dial the number. When the headset is in use the headset indicator (on the **Headset** button) will be lit.
Press **Headset** to end the call.

Receive a call using a headset

When the phone rings and the headset is plugged in, press **Headset** to answer.

Redial (up to last 10 numbers)

Press **Redial**, scroll **↑** or **↓** to the number you want and either lift the handset to dial, or press **Handsfree** or **Headset**.

Handsfree

Press **Handsfree** during a call to switch between earpiece and loudspeaker.

Secrecy

Press **Secrecy** during a call. The red secrecy light (on the **Secrecy** button) comes on and your caller cannot hear you. Press **Secrecy** again to return to your caller.

Adjust the ringer volume

There are 4 volume settings: 1, 2, 3 and Off.

Press **Menu** and scroll **↑** or **↓** to display **Ringer Volume**. Press **✓**.
Scroll **↑** or **↓** to the setting you want.
Press **✓** to confirm. Display shows **Saved**.
Press **Menu** to return to standby.

Adjusting the ringer tone

There are 3 tones to choose from: Tone 1, Tone 2 and Tone 3.

Press **Menu** and scroll **↑** or **↓** to display **Ringer Tone**. Press **✓**.
Scroll **↑** or **↓** to the setting you want.
Press **✓** to confirm. Display shows **Saved**.
Press **Menu** to return to standby.

Caller Display and the Calls list

You must subscribe to a Caller Display service for this feature to work. Your network provider may charge you for this service.

View and dial from the calls list

Press **Calls**. Display shows most recently received call.

Press **↑** or **↓** to scroll through the list.

Lift the handset, or press **Handsfree** or **Headset** to dial a displayed number.

Directory (up to 100 entries)

Storing new directory entries

Press **Menu** then **Menu**. (When you store your very first entry you will not need to press **Menu**).

Display shows **Add New Entry**. Press **✓**.

Display shows **Enter Name**: Enter the name and press **✓**.

Display shows **Enter Number**: Enter the number and press **✓**. The display shows **Entry Saved**.

Dialling a directory entry

Lift the handset or press **Handsfree** or **Headset**.

Press **Menu**. The first number in the directory is displayed.

Scroll **↑** or **↓** to the number you want.

Press **✓** to dial.

One-touch memory buttons (M1-M10)

Store/replace a one touch number

Lift the handset or press **Handsfree** or **Headset**.

Press and hold the grey one touch button that you want to store a number under. Release the button when you hear the dial tone stop.

Enter the telephone number you want to store, then press the same grey one touch button or the **✓** button to save the number.

Slide the memory label out so you can write the number you have stored under each button.

Dial a one-touch number


Lift the handset or press **Handsfree** or **Headset**.

Press the grey one-touch button you want to dial.

Help

Most problems can be fixed with a few simple checks.

Problem	Solution
No dial tone	Only use the cables supplied. Make sure the power adaptor and line cord are plugged into the correct sockets.
You have a dial tone, but the phone will not dial out	If you are connected to a switchboard, check whether you need to dial an access code or if you need to change the dial mode.
Phone ringer does not ring	Is the ringer volume switched off? Adjust the volume.
Using broadband on the same phone line?	Make sure you plug the phone into the wall socket via an ADSL microfilter (not supplied), otherwise you may have problems with this product and your broadband service.



Find out more

- New Frequently Asked Questions available at www.bt.com/producthelp
- If you need more detailed instructions, a full user guide is available to download from www.bt.com/producthelp